



www.RaceWorksInc.com

Finish Line Display Clock Instructions

1. Never turn the timing clocks upside down, always keep them right side up when carrying or storing the clocks.
2. Timing clocks have numerous circuit boards inside that are very sensitive to water. They will short out quickly if they become wet.
3. The clocks operate off DC power and have a charger that convert AC 110 to 12 DC. Do not use any other power than 110 AC to charge or to operate the charger.
4. The on/off switch should always be in the off position when the unit is charging. The on/off switch is located on the right hand side of the clock near the top. Flip the switch up to turn ON and down to turn OFF.
5. Clocks on a full charge should operate for about 6 to 10 hours. However we have noticed if the clocks are left out in the heat or cold before they are used, the charge will only last about 4 to 8 hours.
6. Each clock has a tripod for the clock to be displayed on. The clocks are attached to the tripod with a screw that is permanently attached to the "L-Bracket" of the tripod. This screw is then screwed into the bottom of the time clock. Make sure the screw is secure all the way in to the time clock so that the time clock will not fall off the tripod. The 3 legs on the tripod can be adjusted for the required height. In windy conditions, do not extend the tripod above 4 are feet. The units are top heavy and will blow over very easily.
7. Always use some type of plastic bag to cover the clocks even if it is just start to sprinkle. **DO NOT LET THE CLOCK GET WET.** Use the clear plastic trash bag to cover the clock if it is raining!
8. To start the clock in operation, switch the power switch to "on" position (the switch will then be in the UP position), located on the right hand side of the clock.
9. To reset the clock to "00:00.0" (Make sure the clock is not running) push the "STOP/START" button once on the bottom right hand side of the remote unit. Then push the "RESET PRI button" on the remote. This will clear the unit to "0". When the unit is cleared only one "0" will show.
10. When the air horn or gun goes off push the "START/STOP" button to set the timing clock in motion.
11. If for any reason you missed the start and need to set the timing clock to the official time not a problem. Using the numeric keys in the top portion of the remote, simply enter in the required time where you want the unit to start its timing. When the official time hits the time you have preset on the clock; push the START/STOP button and the clock will begin counting from that point in time.
12. If for any reason the clock would get hung up or you need to adjust the clock again with the official time. Repeat step 12 again.
13. After the event is over; please turn the clocks off and do not allow the battery to drain completely down.
14. Remove the clock from the tripod and return the clock, charger and tripod to RaceWorks. Please inform RaceWorks of any problems you may have in countered. If you have questions please call David Grice at 512-968-0033.